ec_fsm_t
master: ec_master_t *   slave: ec_slave_t *   datagram: ec_datagram_t   master_state: void (*)(ec_fsm_t *)   master_slaves_responding: unsigned int   master_slave_states: ec_slave_state_t   master_validation: unsigned int   slave_state: void (*)(ec_fsm_t *)   sii_state: void (*)(ec_fsm_t *)   sii_offset: uint16_t   sii_mode: unsigned int   sii_value: uint8_t[4]   sii_start: cycles_t   change_state: void (*)(ec_fsm_t *)   change_new: ec_sllave_state_t   change_start: cycles_t   coe_state: void (*)(ec_fsm_t *)   sdodata: ec_sdo_data_t *   coe_start: cycles_t
+ ec_fsm_init(): int   + ec_fsm_clear()   + ec_fsm_reset()   + ec_fsm_execute()   + ec_fsm_startup()   + ec_fsm_startup_running(): int   + ec_fsm_startup_success(): int   + ec_fsm_configuration()   + ec_fsm_configuration_running(): int   + ec_fsm_configuration_success(): int   − ec_fsm_master_start()   − ec_fsm_master_broadcast()   − ec_fsm_master_read_states()   − ec_fsm_master_validate_vendor()   − ec_fsm_master_validate_product()   − ec_fsm_master_rewrite_addresses()   − ec_fsm_master_configure_slaves()

− ec_fsm_master_write_eeprom()
− ec_fsm_startup_start()
− ec_fsm_startup_broadcast()
− ec_fsm_startup_scan()
− ec_fsm_configuration_start()
− ec_fsm_configuration_conf()
− ec_fsm_slavescan_start()
− ec_fsm_slavescan_address()
− ec_fsm_slavescan_state()
− ec_fsm_slavescan_base()
− ec_fsm_slavescan_datalink()
− ec_fsm_slavescan_eeprom_size()
− ec_fsm_slavescan_eeprom_data()
− ec_fsm_slaveconf_init()
− ec_fsm_slaveconf_sync()
− ec_fsm_slaveconf_preop()
− ec_fsm_slaveconf_fmmu()
− ec_fsm_slaveconf_sdoconf()
− ec_fsm_slaveconf_saveop()
− ec_fsm_slaveconf_op()
− ec_fsm_sii_start_reading()
− ec_fsm_sii_read_check()
− ec_fsm_sii_read_fetch()
− ec_fsm_sii_start_writing()
− ec_fsm_sii_write_check()
− ec_fsm_sii_write_check2()
− ec_fsm_change_start()
− ec_fsm_change_check()
− ec_fsm_change_status()
− ec_fsm_change_code()
− ec_fsm_change_ack()
− ec_fsm_change_check_ack()
− ec_fsm_coe_down_start()
− ec_fsm_coe_down_request()
− ec_fsm_coe_down_check()
− ec_fsm_coe_down_response()
− ec_fsm_end()
− ec_fsm_error()